SAITO FA-40a, 40aGK Parts List

NO	Description	Q'ty
01	Cylinder	1
06	Piston	1
07	Piston pin	1
08	Piston pin retainar	2
09	Piston ring	1
10	Connecting rod	1
14	Cylinder screw set(14-1,14-2)	1set
15	Crankcase	1
17	Rear cover	1
19	Breather nipple	1
20	Front bearing	1
22	Rear bearing	1
23	Crankshaft	1
27	Taper collet & Drive flange(27-1,27-2)	1ea.
28	Prop washer & Nut(28-1,28-2)	1ea.
31	Crankcase screw set(31-1,31-2,31-3)	1set
32	Engine gasket set (32-1,32-2,32-3)	1set
33	Cam gear housing	1
35	Cam gear	1
36	Cam gear shaft	1
37	Steel washer set	1set
38	Tappet	2
39	Pushrod	2
40	Pushrod cover & Rubber seal(40-1,40-2,40-3)	2ea.
41	Rocker arm	2

NO	Description	Q'ty
42	Rocker arm screw & Nut(42-1,42-2)	2ea.
43	Rocker arm pin	2
46	Valve set(In & Ex)	1set
47	Valve spring & Keeper & Retainer	2ea.
	47-1,47-2,48	
48	Valve retainer(Cotter)	2
49	Rocker arm cover	2
74	Muffler (with nipple)	1
75	Muffler manifold	1
79	Muffler gasket	2
80	Muffler nut	2
82-1	Carburetor complete	1set
83-1	Carburetor body assembly	1set
	82-1-1,82-1-2,82-1-3,82-1-4,82-1-7,82-1-8 82-1-9,82-1-13	
84	Spraybar assembly(82-1-2,82-1-3,82-1-4)	1set
85	Full throttle needle(85-1,85-2,90-2)	1set
87	Throttle barrel assembly	1set
	82-1-5,82-1-6,88,89,90-1	
88	Throttle lever(88,90-1)	1
89	Idle needle	1
90	Carburetor screw & spring set	1set
	82-1-7,82-1-8,82-1-13,90-1,90-2	
91	Carburetor gasket set(82-1-6,82-1-20,85-2)	1set
110	Anti loosening nut	1

FA-40a