

Specification

Wingspan: 1520mm Fuselage: 1020mm

Flying Weight: 2700-3300g


Motor: EP 3530(4250) / GP 15-20CC

ESC: 40-60A 6S Servo: 17g*4 Prop: 14-15inch


Battery: 6S 2600-4000mAh





Tools





Assemble the Fuselage




































Assemble the Parts
















Assemble the Tail Wing



















Assemble the Servo








Position of center of gravity





ADDITIONAL SAFETY PRECAUTIONS AND WARNINGS

Age Recommendation: This is not a toy, not for children under 14 years old.

- 1.Always keep a safe distance in all directions around your model to avoid collisions or injury. The model is controlled by a radio subject to interference from many sources outside your control. Interference can cause momentary loss of control.
- 2. Always operate your model in open spaces away from full-size vehicles, traffic and people.
- 3.Always carefully follow the directions and warnings for this and any optional support equipment (chargers , rechargeable battery packs, etc.).
- 4.Always keep all chemicals, small parts and anything electrical out of the reach of children.
- 5. Always avoid water exposure to all equipment not specifically designed and protected for this purpose. Moisture causes damage to electronics.
- 6. Never place any portion of the model in your mouth as it could cause serious injury or even death.
- 7. Never operate your model with low transmitter batteries.

